



## **UPR Billet Large Clothes Hanger Install**

## **Tools/Supplies:**

Phillips screwdriver or torx bit

## Parts:

- (2) Large clothes hangers.
- (2) Aluminum spacers.
- (2) Plastic inserts.

## **Estimated Time:**

5-10 Minutes

- 1. Begin by removing the screw on your factory clothes hanger.
- 2. There are two types of mounting holes on Ford vehicles either a square hole or a small circular hole the screw went into. If you have the square hole then place one of the supplied square plastic inserts into the hole.
- 3. Next take the factory screw and push it through the round spacer and bolt it into the factory hole or into the hole in the plastic insert.
- 4. Once tightened then place the hanger over the spacer and tighten the set screw with the supplied allen key.
- 5. Repeat on opposite side.