



UPR Mach 1 Style Grille Delete

- 1. Open the hood of your car and locate the (4) plastic Phillips headed screws holding the top of the factory grille in place. Use a screw driver to remove these screws.
- 2. Remove the (2) plastic retaining screws holding the stock fascia down.
- 3. Next you need to remove the (4) 7mm headed screws on the bottom of the grille you can access them by pulling the grille forward gently so you can reach them from the underside.
- 4. Once the factory grille is removed we recommend cleaning the bumper cover prior to installing the grille delete.
- 5. Slide the grille delete panel in place over the factory fascia and once it's slid into place reinstall the (2) plastic retaining screws through the fascia and the (4) plastic screws that went through the top of the factory grille.