



2020-23 GT500 2024 Mustang Performance Pack / Brembo/ 19" Wheel

Package SHORT IRS Vertical Link Install

SKU 2002-29

1. Jack up the back of the car supporting the body with jack stands.
2. Remove the rear wheels for easier access to the rear suspension.
3. Remove the 15mm top bolt and 18mm bottom bolt holding the vertical link in place.

NOTE: Jacking up the just under the toe link will make removing the stock vertical link easier after it's unbolted. You can use a pry bar or large screwdriver to lightly pry the vertical link loose.

4. Apply grease liberally to the area between the stainless steel washers and the delrin bushings on the bottom half of the vertical link and install in the lower control arm. Reinstall the factory 18mm bolt in the lower part of the link.
5. If you jacked up the arm just under the toe link you can now lower it. To help line up the top of the vertical link you can jack up the lower control arm just under the spring pocket. This will allow you to line up the top of the vertical link and reinstall the 15mm bolt, washer and nut.
6. Torque the top bolt to 129ft lbs and the bottom bolt to 76ft lbs.
7. Reinstall wheels and lower the car back down.

YouTube install Video:

<https://www.youtube.com/watch?v=rObKF6eruGc&t=123s>

Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The buyer has complete responsibility for the installation, use and upkeep of this product

Be sure to shop our online store for the best deals: www.uprproducts.com