Mount

** Be sure to use supplied alcohol pads to prep ** surface before installation of emblems.

Use a sharp razor on a flat surface -- Cut out inside of black box to make template --



Driver Side Template to install on passenger side just use opposite side of template line up arrows same as pictured.

inches wide

Carefully apply inserts and rear adhesive to emblem indoors.

11- inches long