

UPR Oil Catch Can Installation

5032-005 05-10 Mustang oil catch can – driver side

1. Determine mounting location. See recommended location in the photo below. Some models will have a smaller tab on the driver side shock tower. This tab may not have a hole in it for mounting the catch can. You can drill a 1/4" hole for the catch can bracket hardware.
2. Locate the PCV hose connecting the PCV valve on the valve cover to the vacuum fitting to the intake manifold. Remove the PCV hose.
3. The inlet of the catch can will feed into the center diffuser of the catch can. Connect the PCV valve to the inlet side of the catch can.
4. The outlet from the catch can will connect to the intake manifold vacuum fitting.



Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The buyer has complete responsibility for the installation, use and upkeep of this product.