

UPR Oil Catch Can Installation

5049-304-CSCC S650 Procharger Clean Side Catch Can



1. Locate the stud on the rear part of the coolant degas bottle on the driver side shock tower. Install the provided lanyard, then washer, and nut. Tighten the nut with a 10mm deep socket or wrench.



2. Install the Clean Side Catch Can onto the stud and secure it with the supplied knob as shown.



3. Install the short hose from the catch can to the driver side valve cover as shown. The 45 degree fitting will connect to the valve cover , the 90 degree fitting will connect to the catch can.



4. The hose with the 2 90 degree fittings will connect to the supercharger inlet fitting. The long hose with the male fitting will connect to the 90 degree fitting and route under the supercharger towards the catch can.



5. The long hose will connect to forward facing fitting on the catch can.

To check and service the catch can, press the grey buttons on the catch can fittings to release them. NEVER pry the grey buttons out of the fittings. Slide the fittings off of the catch can and unscrew the quick release knob. Unscrew the catch can cup and dispose of the contents with your used drain oil.

Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The buyer has complete responsibility for the installation, use and upkeep of this product