

## Billet A/C Knob Installation



1. Remove the factory A/C Knobs by pulling each knob off.
2. Place the new A/C Knobs on the mounting post making sure to align the notch in the mounting post with the notch in the A/C Knobs. Once aligned, press gently into place.
3. Once installed, test all three A/C Knobs to verify each knob works.