

87-93 Mustang Window Switch Plate Installation

Tools/Supplies:

Clean rag or paper towels, Glass cleaner, Clear Silicone Adhesive.

Parts:

- (1) Driver side window switch plate.
- (1) Passenger side window switch plate.

Estimated Time:

- 15 Minutes
- 1. Begin by cleaning the surface area around your window switches with glass cleaner that contains ammonia. This will help clean off any residue left behind by interior protectents like those found in Armor All.
- 2. Once clean use a piece of regular masking tape and test the area the plate will be mounting to. If the tape sticks it is ready if it does not stick then clean the surface again. We recommend cleaning it at least twice.
- 3. Next take the clear silicone and spread a thin coat of it on the bottom side of the switch plate (use sparingly). Take care not to put too much on the plate and keep it approximately a $\frac{1}{4}$ " away from the edges so that none pushes out once it is pressed in place.
- 4. Next lay the plate into place and press down.
- 5. Let it sit and dry in place. We recommend not trying to clean them or wipe them down (except there is silicone pushing out from the edges) for 24 hours while it is drying.
- 6. Repeat on the other side.

Cleaning Instructions:

The finish on these parts is so fine that it is important to be very careful when cleaning these plates. Use only a clean soft towel or a Viva Kleenex TM type paper towel along with glass cleaner.