



---

## Window Switch Plate Installation (1994-2004 Mustang)

### **Tools/Supplies:**

Clean rag or paper towels, Glass cleaner, Masking Tape.

### **Parts:**

- (1) Driver side window switch plate.
- (1) Passenger side window switch plate.
- (2) Adhesive.

### **Estimated Time:**

15 Minutes

1. Begin by cleaning the surface area around your window switches with glass cleaner that contains ammonia. This will help clean off any residue left behind by interior protectants like those found in Armor All.
2. Once clean use a piece of regular masking tape and test the area the plate will be mounting to. If the tape sticks it is ready if it does not stick then clean the surface again. We recommend cleaning it at least twice.
3. Lay out the pieces and match up the adhesive pieces with each switch plate. The top of each switch plate has a white film on it to protect the finish. The bottom side will be exposed metal.
4. Remove the top of the adhesive and line it up with the bottom of the switch panel and press into place.
5. Next remove the bottom tape from the adhesive strip and put into place on the vehicle.
6. Repeat steps 3-5 for the opposite side.
7. Once both are in place you can now remove the white plastic film on the top of the switch plate. See cleaning instructions below.

### **Cleaning Instructions:**

The finish on these parts is so fine that it is important to be very careful when cleaning these plates. Use only a clean soft towel or a Viva Kleenex **TM** type paper towel along with glass cleaner.