

## Billet Truck Window / Door / Mirror Kit Installation (99-06 Superduty/97-06 F-150/Lightning)

**\*\*While performing this installation make sure to note the orientation of the buttons as you are removing them and installing the new ones. Once they are snapped in it is extremely difficult to take them off without damaging the billet replacements. \*\***

### ***To remove the switch panel:***

1. Lift up vertically on the front edge of the switch panel.
2. It will come loose and you can now disconnect the wires from the switches.
3. Once the panel is removed from the vehicle use a thin flat headed screw driver to free the switches from the panel. They snap in and have little tabs that hold them in.



### ***To remove the factory window, window lock and door lock buttons:***

4. Using a small flat head screw driver gently pry the factory plastic button up.
5. Once it comes free and you remove the button you will see the white square connector to which the button connects to.
6. Be very careful while installing the new switches to keep them facing the proper direction. Line the tabs on the bottom of the billet button up with the square connector and snap it down in place.



### ***To remove the switch panel:***

1. While holding the directional mirror switch to the left, insert a small flat headed screwdriver under the button. Gently pry up on the switch taking care not to mark the door panel. The switch should simply “pop” off. Use the same procedure for removing the Left / Right Selector.
2. Place the new billet mirror switch on the mounting post and gently press down until the switches are fully seated.

