

94-04 Shifter Bezel Install Instructions

Tools:

- (1) 1/16 allen head tool (included)
- (1) 1/8 allen head tool (included)

Parts:

- (1) Billet Shifter Trim Bezel
- (4) 10/32 x 3/8 Stainless steel allen head machine screws
- (6) 4/40 x 1/4 flat allen head screws

Estimated Time:

10-15 minutes.



Install (4) 10/32 allen head screws into bottom of shifter bezel and screw them in until resistance is felt. **DO NOT** tighten the bolts down all the way. There must be .030" clearance (about as thick as a matchbook cover) between the screw head and the bezel. Note the shadow between the screw head and bezel in picture above.



Turn over bezel and install the (6) 4/40 flat allen head screws then press the bezel into place around the factory shifter bezel. It will snap into place.