

2010-2011 Mustang Billet Door Vent Installation



1. Put your window down and remove the factory door vent by gently prying up on the back of the door vent (side nearest to window).
2. Press the door vent into the factory opening. It will snap into place with the interlocking tabs machined into it.
3. Repeat on other side.