

UPR Adjustable Front Control Arm Installation

2004-08, 2004-09, 2004-10



In the hardware kit, you will find 2 grease fittings, 2 cotter pins, 2 large thick washers, 6 long sleeves, and 2 short sleeves. The large washers will be installed between the spindle nut and the spindle when using 94-up spindles.



Arrange the sleeves so that the short ones are towards the front of the car. Install the factory A arm bolts or use UPR's 79-04 Heavy Duty A arm hardware kit 2025-45 (included in UPR's Heavy Duty K member and A arm hardware kit 2025-07). Tighten the A arm hardware just until any slack between the K frame tabs and A arm sleeves is taken up, then hand tighten to snug. Do not overtighten.