

2015+ Mustang Jacking Rail Instructions

Directions:

1. Starting with the driver side remove the 4 (15mm socket) bolts located to the inside of the factory pinch weld (see image below). Some Mustangs have 1 more bolts left out by the factory.
2. Line the driver side (see image below) jacking rail up against the factory pinch weld with the short side of the bracket facing the front of the car (the 2 bolt holes in the front are closer together than the rear ones) and reinstall the 4 (15mm socket) factory bolts or the provided flange bolts into the factory holes.
3. Repeat steps 1 and 2 for the passenger side.

