



## **UPR 7075 Billet Aluminum Lug Nuts**

1. Before attempting to install the UPR lug nuts, make sure you have the correct thread and type.
2. Apply anti seize to the wheel studs before installing lug nuts. (A little goes a long way)
3. Torque the lug nuts to spec by hand using the appropriately sized 12 point socket.
4. **DO NOT USE AN IMPACT GUN ON ALUMINUM LUG NUTS.** Modern electric and air impact guns can produce tremendous amounts of torque and will damage aluminum lug nuts.
5. Re check lug nut torque regularly.

**5/8" stud Lug nuts - 100 Ft/lbs**

**1/2" stud Lug Nuts - 85 Ft/lbs**

**12mm stud Lug Nuts - 85 Ft/lbs**

**14mm stud Lug Nuts - 85 Ft/lbs**

**You will need a 7/8 12 point socket**

*Make sure your socket is in good condition.*

*If it is worn, it may damage the Lug nuts.*

Lug nuts that have been installed incorrectly or damaged due to mis use will not be covered under warranty.

*Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The purchaser or user of this product is responsible for the proper disposal of any hazardous materials (oil catch can contents). The buyer has complete responsibility for the installation, use and upkeep of this product.*

***Be sure to shop our online store for the best deals: [www.uprproducts.com](http://www.uprproducts.com)***