


## **UPR Oil Catch Can Installation**

## 2020 – 22 Ford Explorer ST, XLT 3.0 EcoBoost single valve catch can 5028-278



1) Find the un-used factory hole in the radiator support just to the left of the hood bumper. Mount the catch can with the provided hardware. You will need a 5/32 allen wrench.



2) Locate the factory PCV hose. It runs from PCV on the passenger valve cover to the intake manifold vacuum port. Remove the hose. Keep the hose in case the vehicle is to be put back to stock.



<u>www.uprproducts.com</u> • sales@uprproducts.com



3) The outlet from the catch can will be marked with a silver Sharpie at the end. Install the vacuum hose by connecting from the outlet of the catch can to the intake manifold vacuum port. If you selected the Pro Series Check Valve upgrade, be sure the arrow printed on the check valve faces away from the catch can, towards the engine.



4) Connect the Dirty Side hose from the PCV on the passenger side valve cover to the inlet fitting on the catch can. Route the hoses so they are clear from hazards like belts, fans or exhaust.

Always check and drain the catch can more often in winter / freezing weather. If the water/oil mixture in the catch can is allowed to freeze it will cause damage to the catch can and internal components. Any damage due to freezing is NOT WARRANTY. You must dispose of the liquid collected in the catch can properly (with used waste oil) properly according to your local laws.

<u>Product Liability Statement:</u> The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The purchaser or user of this product is responsible for the proper disposal of any hazardous materials (oil catch can contents). The buyer has complete responsibility for the installation, use and upkeep of this product.