

UPR Oil Catch Can Installation 2021 Jeep Rubicon 392 Hemi



1. Remove the nut from the coolant degas bottle bracket, install the UPR catch can bracket and reinstall the nut as shown.



2. Locate the factory PCV hose and remove it from the rubber boots. Connect the hoses to the catch can as shown with the supplied adapter fittings.

Always check and drain the catch can more often in winter / freezing weather. If the water/oil mixture in the catch can is allowed to freeze it will cause damage to the catch can and internal components. Any damage due to freezing is NOT WARRANTY. You must dispose of the liquid collected in the catch can properly (with used waste oil) properly according to your local laws.

Be sure to shop our online store for the best deals: www.uprproducts.com



750 Eastcoast St South • Lake Worth, FL 33460
561-588-6630 • Fax: 561-585-4141
www.uprproducts.com • sales@uprproducts.com

Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The purchaser or user of this product is responsible for the proper disposal of any hazardous materials (oil catch can contents). The buyer has complete responsibility for the installation, use and upkeep of this product.

Be sure to shop our online store for the best deals: www.uprproducts.com