

## **UPR Oil Catch Can Installation**

## 19 – up GM CHEVROLET GMC TRUCK 5.3L SINGLE VALVE CATCH CAN PLUG N PLAY

- 1. Remove the battery hold down bolt, and install your UPR Catch Can in this location. Do not tighten bolt until the rest of the steps are completed.
- 2. Remove the PCV hose connecting the driver's side the valve cover to the vacuum port on the side of the intake manifold.
- 3. Install the 'Clean Side' hose (if you selected to add the Billet Pro Series check valve, the arrow faces the engine) to the side fitting on the catch can, and connect the other end to the vacuum on the side of the intake manifold.
- 4. Install the "Dirty Side" PCV hose onto the top fitting of the catch can, and connect it to the driver side valve cover.
- 5. Go back and tighten the catch can mount (bolt on battery hold down)





Tips: Be sure to check your catch can in 1000 mile intervals until you do your first oil change so you know how much oil your PCV system is ingesting and how frequent to check the can. 2. In colder months you will need to check the catch can more frequent as it will collect moisture and need to be emptied. 3. Cleaning tips you will only use a good quality dish soap and nothing else to cut and oil or much that collects over time. As any other cleaner can damage the anodizing and discolor the can.

Always check and drain the catch can more often in winter / freezing weather. If the water/oil mixture in the catch can is allowed to freeze it will cause damage to the catch can and internal components. Any damage due to freezing is NOT WARRANTY.

<u>Product Liability Statement:</u> The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The buyer has complete responsibility for the installation, use and upkeep of this product.