



11-14 F150 3.5L Ecoboost UPR Single Valve Oil Catch Can Installation

****The Arrow on the Check Valve always faces away from the UPR Catch Can****

1. Start by relocating the ACT sensor from the upper radiator core support, down to the bracket on the lower passenger side of the condenser.
2. Install the provided bolt into the hole where the ACT sensor was removed. Install the catch can onto the bolt and use the lock nut to securely fasten the catch can.
3. Route both hoses around the passenger side of the radiator, and remove your engine cover if equipped.
4. The hose coming from the top of the catch can attaches to the passenger side valve cover. This line does **NOT** have a check valve.
5. The hose coming from the side of the catch can routes to the intake manifold. This line **HAS** a check valve. Make sure the arrow on the check valve face away from the UPR Catch Can
6. Ensure that all connections are snug and the UPR Catch Can hardware is tight. Re-install your engine cover if you desire when you are finished

Never use the oil again that is collected in your catch can.

[UPR Products Catch Can Installation Photos can be viewed at the address below.](#)

<http://www.uprproducts.com/ford-f150-billet-oil-catch-can-single-valve-ecoboost-11.html>

Be sure to shop our online store for the best deals: www.uprproducts.com