

## 79-04 Mustang UPR Oil Catch Can Installation

79-04 Mustang Assembly & Installation Instructions:

1. Determine mounting location.
2. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
3. If you selected the magnetic drain plug or drain line kit, screw the pipe plug or petcock into the bottom of the can.
4. Mount the can to the location of your choice. The radiator overflow tank bracket is one suggestion.
5. Route the hose from the valve cover to the inlet side of oil catch can ( the inlet will connect to the center of the catch can) then from the other side of the catch can to the intake tube. Layout the supplied hose and cut to proper length.
6. Push the hose onto the valve cover and onto one side of the oil catch can barb.
7. Push the other hose onto the other side of the oil catch can and then onto the intake tube.

**NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE**



*Be sure to shop our online store for the best deals: [www.uprproducts.com](http://www.uprproducts.com)*