

## 05-10 Mustang UPR Oil Catch Can Driver Side Installation

05+ Mustang Assembly & Installation Instructions:

1. Determine mounting location. See recommended location below.
2. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
3. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
4. Using the existing hole, mount the oil catch can to the top of the strut tower.
5. Find the hose going from the valve cover to the intake and remove it.
6. The new routing of the hose should go from the valve cover to the oil catch can inlet then from the outlet side of the catch can to the intake. Layout the supplied hose and cut to proper length.
7. Push the hose onto the valve cover and onto one side of the oil catch can barb.
8. Push the other hose onto the other side of the oil catch can and then onto the intake.

### **NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE**



*Be sure to shop our online store for the best deals: [www.uprproducts.com](http://www.uprproducts.com)*