

UPR Billet Catch Can Diffuser Installation

Assembly & Installation Instructions:

1. Remove UPR Catch Can.
2. Unscrew Catch Can top.
3. Remove the O-ring holding the screen in place.
4. Install the UPR Catch Can Diffuser with the extended chamber going on the inlet side.
5. Re-install O-ring around diffuser to secure it in place.
6. Screw the two pieces of the catch can back together and re-install in the vehicle.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE



Be sure to shop our online store for the best deals: www.uprproducts.com