

Driveshaft Safety Loop 2011~ Current Mustangs (DSL-M03)

Doesn't get much simpler than this, bolts directly to transmission mount. Quick and easy bolt-in application requires no drilling or welding and is lightweight. Both loop and base plate are slotted to allow for height adjustment. Designed for **ALL** automatic and manual applications, works with **aftermarket aluminum driveshafts** and **exhaust** too!

Designed to work with 6R80, 10R80 & MT82 transmissions.

(<u>Please read all instructions prior to beginning installation. Contact your dealer with any questions.</u>)

Kit Includes:

- 1 DSL base plate
- 1 DSL loop
- 4 3/8-16 x 1 Hex Head Bolts
- 4 3/8-16 Pinch Nuts
- 4 3/8 SAE Flat Washers

Installation:

- 1. Raise vehicle to allow access for installation; support with jackstands.
- 2. Support transmission with floor jack. Do not block access to cross-member mount or support on transmission pan.
- 3. Remove the three bolts attaching transmission to the vertical part of transmission mount.
- 4. Align DSL base plate to vertical face of mount and fasten into place using the OEM bolts. Torque bolts to 76ft-lbs. [Note: Holes in base plate are slotted to allow for additional vertical adjustment. Confirm clearance between top edge of base plate driveshaft flange before torqueing into place.]

Required Tools: Floor jack

Basic hand tools

Install Time: Approximately 1/2 hr.

- 5. Position DSL loop over mounting tabs on base plate. Insert four 3/8" bolts from the outside and loosely secure with supplied washers and nuts.
 - [Note: When installing loop, it may be helpful to bring from the rear forward, following the driveshaft.]
- 6. Confirm adequate clearance (1/4"min.) between DSL and driveshaft assembly, adjust if necessary, and tighten into place.
- 7. Remove floor jack and jackstands and lower car.

