


11+ Mustang GT Drive Shaft Loop Instructions

Assembly & Installation Instructions:

1. Remove the 2 rear factory transmission cross member bolts.
2. Install the long mounting bracket using the factory or supplied 12mm bolts and washers.
3. Place the loop onto the driveshaft and slide it out of the way for now. It's easiest to slide over the driveshaft right by the front yoke at its narrowest point.
4. Install the angled bracket onto the long mounting bracket with the slotted holes and with the bracket facing the rear of the car using the provided 3/8" bolts, flat washers, lock washers and nuts. Do not tighten them yet.
5. Position the loop onto the angled bracket and bolt them together with 3/8" bolts, lock washers and nuts.
6. Adjust the loop left to the right so the driveshaft is in the center of the loop and tighten all hardware.



Be sure to shop our online store for the best deals: www.uprproducts.com